
LAMP, HG-TQJ100 ADJUSTABLE ONE WAY TORQUE HINGE Installation Instructions

Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.


Item Code	Item Name	Torque working Direction	Torque
170-032-969	HG-TQJ100-A	Opening	0-10N·m(0-102kgf·cm)
170-032-970	HG-TQJ100-B	Closing	0-10N·m(0-102kgf·cm)

INSTALLATION PROCEDURE

1.Remove the covers by screw driver.




Fix hinges with the screws.




3. Adjust the torque of hinges to work torque effectively.

Please adjust the torque by fixing the screw slotting. It prevents screw idles of torque adjustment screw.



4. Put the covers on the hinges.



SUGATSUNE KOGYO CO.,LTD Tokyo, JAPAN Phone: +81 (0)3 3866 2260 E-mail:export@sugatsune.co SUGATSUNE KOGYO (UK) LTD eading, UK none: +44 118 9272 955 E-mail:sales@sugatsune.co.uk

SUGATSUNE SHANGHAI Co., LTD Shanghai, CHINA ip Phone: +86 21 3632 1858 E-mail:lamp@sugatsune.com.cn Guangzhou, CHINA E-mail lamp@sugatsune.com.cn

SUGATSUNE KOGYO INDIA PRIVATE LIMITED
Mumbai, INDIA
Phone: +1 514 312 5267 E-mailsuppor

SUGATSUNE AMERICA, INC

ne: +1 310 329 6373 E-mail:sales@sugatsune.com Chicago, USA

1 312 461 1081 E-mail:chicagoshowroom@sugatsune.com.

hone: +1 514 312 5267 E-mail:support@sugatsune.ca

2017.08 0950-3