
LAMP

MULTI-PURPOSE LID(W/DAMPER&LOCK) AZ-GD230L-HL Installation instructions

Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.

ABOUT THE PRODUCT

- Damper allows silent closing of lid.
- Lid can be looked to block throwing in during the time of non-use.
- With red indicator of lock.
- Side plates for anti-pinch function.



FOR YOUR SAFE WORK AND OPERATION

Meaning of symbols

Warning **Caution**







Paution: If these cautions are not followed, it may result in injury or damage.

- 1 To avoid any risk of accidental fall and injury, ensure that the product is securely fastened to a support with adequate strength.
- Any attempt to dismantle, modify or use in any way other than those described in this document, may result in damage or injury.
- Ambient temperature range is 0 to 40° C
- 1 The closing speed of the lid may vary according to ambient temperature. If the product is stored below zero degree, please use it after several hours of storage in normal room temperature.

PARTS DESCRIPTION


Description	Quantity
Flap lid body	1
Warning sticker	1
Cover cap	4
key	3

TOOLS NEEDED FOR INSTALLATION


Screws (not provided)

Choose the suitable length according to the material to be mounted. Recommended screw: Tapping screw Nominal 3 · · · · · 4 pcs

DIMENSION DRAWING



CUTOUT DIMENSIONS






INSTALLATION


1.

Make sure that the LAMP logo is at the top.




2.

Do not leave any gap between the body and the mounting surface.



- 3-1 Having opened the lid, insert the screws through the provided access holes (two on each side) and fasten the flap lid body securely.
- 3-2 Make sure that the final assembly is securely fastened.




4.

Slowly open and close the lid completely a few times in order to make sure that there are no obstacles such as the bottom edge of the cutout or any item inside.


5.

Check if the lock works properly.



6.

Cover the screwdriver access holes with the caps provided.



E-mail:lamp@sugatsune.com.cn

E-mail:lamp@sugatsune.com.cn

Paste the warning sticker in a visible position to avoid any injury when operating the lid.



SUGATSUNE KOGYO CO.,LTD

Tokyo, JAPAN Shanghai, CHINA
Phone: +81 (0)3 3866 2260 E-mail:export@sugatsune.co.jp Phone: +86 21 3632 1858

SUGATSUNE KOGYO (UK) LTD

SUGATSUNE EUROPE GmbH

SUGATSUNE KOGYO INDIA PRIVATE LIMITED Mumbai, INDIA
Phone: +91 22 28314490/91 E-mail:sales@sugatsune.in

SUGATSUNE CANADA, INC.
Phone: +1 514 312 5267 E-mail:support Phone: +49 211 53812900 E-mail:sales@sugatsune.eu

SUGATSUNE SHANGHAI Co., LTD

Guangzhou, CHINA

ISO9001(Japan Offices and Sugatsune America) and ISO14001(Chiba Production division and Logistics center), certified.

SUGATSUNE AMERICA, INC

California, USA
Phone: +1 310 329 6373 E-mail:sales@sugatsune.com Chicago, USA Phone: +1 312 461 1081 E-mail:chicagoshowroom@sugatsune.com

Phone: +1 514 312 5267 E-mail:support@sugatsune.ca

2018 02 1212-1